




## Resortes para zapatas Chevrolet - GM

Chevrolet - GM brake shoe springs

Molas para sapatras Chevrolet - GM








	Código / Code	Modelos / Models	Sistema / System
	H-5040	C 60 - 714	Frenarsa
	H-5047	C 60 - 714	Frenarsa
	H-5125	C 60 - 714	Frenarsa

## Resortes para zapatas Dodge

Dodge brake shoe springs

Molas para sapatras Dodge











	Código / Code	Modelos / Models	Sistema / System
	H-5300	D600	Bendix
	H-5305	D600	Bendix
	H-5040	DP800	Frenarsa
	H-5047	DP800	Frenarsa
	H-5125	DP800	Frenarsa

# Resortes para zapatas El Detalle

El Detalle brake shoe springs

Molas para sapatas El Detalle













	Código / Code	Modelos / Models	Sistema / System
	H-5035	OA 101	Frenarsa
	H-5040	OA 101	Frenarsa
	H-5080	OA 101	Master
	H-5082	OA 101	Master
	H-5084	OA 101 Trasero / Rear / Traseiro	Master
	H-5047	OA 101	Master
	H-5624	OA 105	Eaton
	H-5625	OA 105 Delantero / Front / Dianteiro	Eaton
	H-5626	OA 105 Trasero / Rear / Traseiro	Eaton
	H-5628	OA 105	Eaton

## Resortes para zapatas Fiat / Iveco

Fiat / Iveco Brake shoe springs

Molas para sapatas Fiat / Iveco













	Código / Code	Modelos / Models	Sistema / System
	H-5300	673 - 150	Bendix
	H-5305	673 - 150	Bendix
	H-5200	619	Fiat
	H-5210	619	Fiat
	H-5205	619	Fiat
	H-5215	619	Fiat
	H-5080	Eurocargo	Master
	H-5082	Eurocargo Eurotrakker - Eurotech Trasero / Rear / Traseiro	Master
	H-5084	Eurotrakker - Eurotech Delantero / Front / Dianteiro	Master
	H-5047	Eurocargo / Eurotrakker / Eurotech	Master

# Resortes para zapatas Ford

Ford Brake shoe springs

Molas para sapatillas Ford











	Código / Code	Modelos / Models	Sistema / System
	H-5300	F 700 / F 7000	Bendix
	H-5305	F 700 / F 7000	Bendix
	H-5080	F 14000 / Cargo	Master
	H-5082	F 14000 / Cargo	Master
	H-5047	F 14000 / Cargo	Master
	H-5307	Cargo	Bendix
	H-5412	Cargo C 814	Master
	H-5413	Cargo C 814	Master
	H-5414	Cargo C 814	Master
	H-5415	Cargo C 814	Master

# Resortes para zapatas Mercedes Benz

Mercedes Benz brake shoe springs

Molas para sapatas Mercedes Benz








	Código / Code	Modelos / Models	Sistema / System
	H-5040	L 1114 / LO 1114	Frenarsa
	H-5035	L 1114 / LO 1114 / L 1517	RG
	H-5050	L 1114 / LO 1114 / L 1517	RG
	H-5047	L 1114 / LO 1114 / L 1517	RG
	H-5675	L 1114 / LO 1114	Volteo
	H-5676	OH 1315 / OHL 1420	Volteo
	H-5624	OHL 1621L	Eaton
	H-5625	OHL 1621L Delantero / Front / Dianteiro	Eaton

## Resortes para zapatas Mercedes Benz

Mercedes Benz brake shoe springs

Molas para sapatas Mercedes Benz







	Código / Code	Modelos / Models	Sistema / System
	H-5626	OHL 1621L Trasero / Rear / Traseiro	Eaton
	H-5628	OHL 1621L	Eaton
	H-5674	Accelo Trasero / Rear / Traseiro	Volteo
	H-5695	LO 814 Trasero / Rear / Traseiro	RG
	H-5630	LO 814 Trasero / Rear / Traseiro	RG

## Resortes para zapatas Scania

Scania Brake shoe springs

Molas para sapatas Scania








	Código / Code	Modelos / Models	Sistema / System
	H-5955	111 Delantero / Front / Dianteiro	Scania
	H-5960	K112 Delantero / Front / Dianteiro	Scania
	H-5950	111 - K112 Trasero / Rear / Traseiro	Scania
	H-5980	K113 Trasero / Rear / Traseiro	Scania

# Resortes para zapatas Volkswagen

Volkswagen Brake shoe springs

Molas para sapatillas Volkswagen














	Código / Code	Modelos / Models	Sistema / System
	H-5080	16.180 / 24.200 / 26.260	Master
	H-5082	16.180 / 24.200 / 26.260	Master
	H-5047	16.180 / 24.200 / 26.260	Master
	H-5412	7.100 / 8.140	Master
	H-5413	7.100 / 8.140	Master
	H-5414	7.100 / 8.140	Master
	H-5415	7.100 / 8.140	Master

## Resortes para zapatas Remolques

Trailers brake shoe springs

Molas para sapatas Reboques



	Código / Code	Modelos / Models	Sistema / System	Largo / Length / Longo
	H-5020	Helvética ganchos móviles modelo viejo old model modelo velho	Helvética	134 mm.
	H-5015	Helvética modelo viejo old model modelo velho	Helvética	163 mm.
	H-5005	Helvética M70	Helvética	160 mm.
	H-5025	Helvética FM8	Helvética	170 mm.
	H-5030	Maldonado modelo viejo old model modelo velho	Maldonado	160 mm.
	H-5035	Montenegro	Frenarsa	173 mm.
	H-5040	Montenegro	Frenarsa	185 mm.
	H-5042	Montenegro	Frenarsa	200 mm.
	H-5045	Montenegro	Frenarsa	85 mm.
	H-5047	Montenegro	Frenarsa	80 mm.
	H-5050	Montenegro	Frenarsa	













# Resortes para zapatas Remolques

Trailers brake shoe springs

Molas para sapatas Reboques



	Código / Code	Modelos / Models	Sistema / System	Largo / Length / Longo
	H-5055	Prati	Prati	167 mm.
	H-5060	Prati	Prati	135 mm.
	H-5065	Prati	Prati	158 mm.
	H-5080	Randon	Master	210 mm.
	H-5081	Randon	Master	224 mm.
	H-5084	Randon	Master	215 mm.
	H-5082	Randon	Master	139 mm.
	H-5052	Randon	Master	
	H-5070	Salto modelo viejo old model modelo velho	Salto	273 mm.
	H-5075	Salto modelo nuevo new model modelo novo	Salto	265 mm.