

## Grampas artilleras Dodge

Dodge rim clamps  
Castanhas de roda Dodge



	Código/Code	Modelos/Models	Posición / Position	Ø
	J-4090	D800	Delantera Front Dianteira	3/4
	J-2091	D800	Trasera Rear Traseira	3/4

## Grampas artilleras Fiat

Fiat rim clamps  
Castanhas de roda Fiat

	Código/Code	Modelos/Models	Posición / Position	Ø
	J-3090	673 / 619 / 697	Delantera Front Dianteira	18mm.
	J-3091	673 / 619 / 697	Trasera Rear Traseira	18mm.

## Grampas artilleras Ford

Ford rim clamps  
Castanhas de roda Ford

	Código/Code	Modelos/Models	Posición / Position	Ø
	J-4090	F7000	Delantera Front Dianteira	3/4
	J-4091	F7000	Trasera Rear Traseira	3/4

## Grampas artilleras Iveco

Iveco rim clamps  
Castanhas de roda Iveco



	Código/Code	Modelos/Models	Posición / Position	Ø
	J-3090	150	Delantera Front Dianteira	18mm.
	J-3091	150	Trasera Rear Traseira	18mm.

## Grampas artilleras Scania











Scania rim clamps  
Castanhas de roda Scania

	Código/Code	Modelos/Models	Posición / Position	Ø
	J-9850	Scania	Delantera Front Dianteira	3/4
	J-9851	Scania	Trasera Rear Traseira	3/4
	J-9852	Scania Bus	Delantera Front Dianteira	18mm.

# Grampas artilleras Remolques

Trailers rim clamps  
Castanhas de roda Reboques



	Código/Code	Modelos/Models	Ø
	J-0230	Construcciones Metalúrgicas	3/4
	J-4091	Dana (WEBB 16123)	3/4
	J-4093	Dana (WEBB 3320)	3/4
	J-0260	Golondrina	3/4
	J-0390	Helvética	5/8
	J-0391	Helvética / Sola y Brusa	3/4
	J-0393	Helvética reforzada	3/4
	J-0392	Helvética	3/4
	J-0690	Montenegro	5/8
	J-0691	Montenegro	3/4

# Grampas artilleras Remolques

Trailers rim clamps  
Castanhas de roda Reboques



	Código/Code	Modelos/Models	Ø
	J-0790	Prati 85->	3/4
	J-0791	Prati	3/4
	J-0792	Prati	3/4
	J-0793	Prati Fruehauf	3/4
	J-0800	Randon	20mm.
	J-0890	Salto	3/4