








Guías de suspensión neumática



	Código / Code	Modelos / Models	Posición / Position
	A-4622	Storani KLL	Exterior
	A-4623	Storani KLL	Interior
	A-4615	KLL	

Arandelas de suspensión neumática

	Código / Code	Modelos / Models	∅ int.	∅ ext.
	A-4628	Boero	30 mm.	100 mm.
	A-4629	Boero	58 mm.	100 mm.
	A-4624	Storani KLL	59 mm.	177 mm.
	A-4627	Storani	55 mm.	159 mm.